

EVOLVE[®]

Ptero TC 1, 13.4 W/mK

Application guide

1. Clean the CPU&heat sink surface by cleaning wipe.

2. Apply the thermal grease on the CPU chip (a dot or cross sharp are both OK).



3. Smear the thermal grease evenly by the spatula/screw scrapper/flat, thinner is better.



4. Install the heat sink on the CPU

www.evolveo.com

EVOLVE⁰

Ptero TC 1, 13.4 W/mK

Návod na aplikaci pasty

1. Vyčistěte povrch procesoru a chladiče čistým hadříkem.

2. Aplikujte termální pastu na čip procesoru (tečka nebo kříž, obě varianty jsou v pořádku).



3. Nanesenou pastu rovnoměrně rozetřete stěrkou nebo škrabkou.



4. Nainstalujte chladič na CPU

www.evolveo.com